





MCB Tripping Issue?

01	<p>Ensure that the supply cable (Red & Black - Phase & Neutral) are properly connected with the White OC connector. (AC supply across the wires at both the points A and B should be within the range of 140V to 285V.)</p>	
02	<p>Ensure that the fan wires aren't short circuited with the fan's hook.</p>	
03	<p>Ensure that MCB is not overloaded with multiple equipment connections. You may take the help of an electrician for the same.</p>	
04	<p>MCB must not be tripped & the supply switch/button should be "ON".</p>	
05	<p>Ensure that the MCB is not faulty. You may take the help of an electrician for the same.</p>	